



Atwood Mobile Products LLC
 1120 North Main Street • Elkhart, IN 46514
 PHONE: 574-264-2131 FAX: 574-262-2550
 INTERNET: <http://www.atwoodmobile.com>

LITERATURE NUMBER **MPD 87297**

LATCH REPLACEMENT



ENGLISH, FRANÇAIS (et Canada)

•Installation •Operation •Maintenance

Effective 10/10/06

2" Yoke Style Coupler

2-5/16" Yoke Style Coupler



For complete coupler instructions consult MPD 87984.



WARNING
 PERSONAL INJURY/PRODUCT DAMAGE

- Replace couplers that are worn or damaged, or not operating freely.



WARNING
 PRODUCT DAMAGE

- Coupler must be disengaged from hitch ball.
- Latch must be in closed position for repairs.


TO TAKE APART

1. Grind off staked end of pin (FIG 1 & 2-C) that goes through nose of coupler.
2. Slide pin out side of coupler.
3. Remove ball clamp (FIG 1 & 2-B) from under side of coupler nose.
4. Remove latch and yoke assembly from top of coupler nose.
5. Discard old parts. **DO NOT REUSE!**

INSTALLATION PROCEDURE

1. Place latch and yoke assembly (FIG 1 & 2) over coupler nose and align holes on yoke assembly with holes on sides of coupler nose and hold in place.
2. Place ball clamp (FIG 1-B & 2-B) inside nose of coupler and align its holes with holes in yoke assembly and holes in sides of coupler nose.
3. **For 2" coupler -**
 - a. Place insert sleeve (FIG 1-E) into ball clamp (FIG 1-B) and install under coupler nose.
 - b. Place washer (FIG 1-F) on bolt (FIG 1-C).
 - c. Align the hole in the latch yoke assembly (FIG 1 A) and insert sleeve/ball clamp assembly (FIG 1 B & E) with the hole in the coupler nose. Then install bolt assembly (FIG 1 C & F) through both sides of coupler nose.
 - d. Place other washer (FIG 1-H) and nut (FIG 1-D) on exposed threaded portion of bolt and torque nut to 15 ft. lbs.
3. **For 2-5/16" coupler -**
 - a. Place ball clamp (FIG 2-B) under coupler nose.
 - b. Align the hole in the latch and yoke assembly (FIG 2-A & G) and ball clamp (FIG 2-B) with the hole in the coupler nose. Install the hole in the coupler nose followed by the bolt (FIG 2-C).
4. Check coupler for proper latching on a proper diameter ball. Insert ball, close coupler. The two legs of the latch handle (FIG 1 & 2-G) MUST fit snugly into the mating 2 slots on top of the coupler.

"Marvel"




COUPLER REPAIR KITS 88060/88050

1. Lock and shoe assembly
2. Coupler spring
5. Handle
6. Roll pin

COUPLER REPAIR KITS 88061/88051

1. Lock and shoe assembly
2. Coupler spring
3. Retainer spring
4. Spring retainer
5. Handle
6. Roll pin

"John Deere"



COUPLER REPAIR KIT 07532

1. Plunger, link spring assembly
2. Cam and handle assembly
3. Rivet