



Aaron Zimmer architect






BREAKER PANEL



Questions:

- 1. Which battery terminal is positive and which is negative?
- 2. I've noticed most of the fusable-links are 30A, but a few are 20A. Does it make a difference if I make them all 30A?
- 3. Where/what are the orange wires for? Why would a previous owner have disconnected and removed the components to one of them?
- 4. Two black loose wires: for the 12V water pump? How do I connect them to the battery?
- 5. Green wire. Does it typically ground to the aluminum frame? Or is it grounding somewhere inside the frame to an alternate ground? Does aluminum suffice?
- 6. How is my battery suppose to charge? I have a '63, no Univolt charging system. From all I've read, it's suppose to charge off of the auto battery. How?




WHICH ONE IS POSITIVE? WHICH IS NEGATIVE?

BATTERY COMPARTMENT


This is a brand new battery. I'm thinking about picking up a 12V 5W solar charger from BatteryMinder to bypass a charger/inverter system. Anyone have any NEGATIVE experience with these particular units?

P.S. I live in sunny Colorado.









SINK LIGHT SCHEMATIC

