

The temp sender fitting installs in the trani hose marked with the blue arrow below. The hose is located below the radiator. Use the fuel injector style hose clamps provided when clamping the hose over the barbed ends of the fitting. Using pull ties, secure the fitting to the metal pipe immediately this hose.

Note that the 1/8" NPT threads are recessed in the fitting's bushing. You must install a sender unit that will accommodate this recess.

