


SET TERMINAL	REMOTE SWITCH TERMINAL	FUNCTION	WIRE COLOR CODE	
1	1	Ground	Black	
2	2	Stop	Brown	
3	3	Start	Yellow	
5	5	Battery Condition Meter	Orange	IF USED
6	6	Lamp and Running Time Meter	Red	

FIGURE 11. WIRING CONNECTIONS FOR 300-0985 AND 300-0986 REMOTE CONTROLS